

## Media settings guide for Inkjet Printers

The recommendations listed below are a starting point and to be used primarily as a guide.

It is recommended that the highest resolution be used to obtain the optimum performance.

### Epson (dye based)

Stylus Color, 200, 300, 400, 440, 480, 500, 600, 640  
740, 760, 800, 850, 880, 900, 980, 1160, 1520, 3000  
Stylus Photo, 700, 750, 780, 810, 830U, 870, 890, 1200,  
915, 825, 930, 935, 950, 960, 820, 895, 1270, 1290, 1290S  
R200, R300, RX500, RX600  
Stylus Pro, Pro XL, 5000, 5499

### Epson

#### (pigment based)

Stylus Photo 2000P  
Stylus Photo 2100  
C43, 44, 62, 82 series  
C64, C64 PE, C84, C84 PE  
CX5400, 6400  
R800

### Hewlett Packard

Deskjet 500,600,700,800,900,1100, CP1700, CP1160  
3820, 5150, 5550, 6122, 6127, 7150, 7350, 7550, 9300  
5600, 5850, 9300, 3500, 3600, 450, 1220, 350c/cbi  
All in one psc1205,1210,2110,2115,2170,2175,2210,  
Photosmart 130, 230, P1000, P1100, P1200, P1300 series  
Photosmart 140, 240, 2400, 2500, 7200, 7600, 7900 series  
Business 2000, 2200, 2230, 2280, 2250, 2500, 3000  
OfficeJet G45, 55, 75, 95, 5110, v40, k80, d145, d155xi  
Office Jet 5500,6100,7100,6110,7110,7130,7140xi,9110,9120

### Canon

BJC 50,55,65,75,80,85,250  
1000,2000,3000,4000, 6000  
7000, 8200,250,320, 350, 850, 950  
S200x,330,550d,750,820,830, 530D  
S6300, S9000 series  
i70, i80, 450, i455, i470D, i475D, i560  
i865, i905D, i965, i990, i9500, i9100  
i550, i6500, i9100

### Lexmark

Z13, 23, 33, 43  
Z52, 53, 65, 85, z515, z615  
Z600 series, i3  
P700 series  
X1130, 1150, 2250  
X5150,4250,5190,5190pro,6150  
X6170, 6190, X6190pro,

Media Type	Print mode			
	Photo Quality Glossy Film	Premium Glossy Photo Paper	Matt Paper Heavyweight	Photo Quality Inkjet Paper
310gsm Fine Art			**	*
300gsm Gloss	**			
270gsm D/S Gloss	**	*		
260gsm Gloss	**	*		
260gsm Satin	**	*		
230gsm Matt			**	*
180gsm Matt			**	*
170gsm Gloss	**			
170gsm Satin	**	*		
170gsm D/S Matt			**	*
120gsm Matt			*	**

Print mode		
Premium Semigloss Photo Paper(2100)	Watercolour Paper - Radiant white (2100)	Archival Matte(2000P only)
	**	**
NA	NA	NA
**	*	**
**	*	**
**	*	**
	**	**
	**	**
NA	NA	NA
NA	NA	NA
	**	**
	**	**

Print mode				
HP Premium Plus Photo Paper, Glossy	HP Deluxe Photo Paper	Photo Paper	Premium Inkjet Heavyweight Paper	Premium Inkjet Paper
			**	*
	*	**		
**	*			
**	*			
	*	**		
			**	*
			**	*
*	**			
**	*			
			*	**
			*	**

Print mode		
High Gloss Photo Film	Glossy Photo Paper	Photo Paper Pro
	**	*
*		**
*		**
*		**
*		**
	**	*
	**	*
*		**
*		**
	**	*
	**	*

Print mode	
Glossy/ Photo Paper*	Coated Paper*
*	**
**	*
**	*
**	*
**	*
*	**
*	**
**	*
**	*
*	**
*	**

Key

\*\* - Recommended

\* - Alternative

\*See below specifics in brackets

\* Use best setting on all

For more specific information on individual printer settings consult our website - [www.ici-imagedata.com](http://www.ici-imagedata.com)